



Audi TT Coupé

Quick reference guide



Fuel tank flap

To open:

Press the  switch on the driver's door.

To close:

Press the tank flap until you hear it click into place.




Fuel

(see sticker)

Tyre pressures

(see sticker on door pillar on driver side)




Warning triangle

The compartment for the warning triangle is located in the luggage compartment.



Engine oil

The correct oil specifications and engine oil capacity are listed in the Performance, weights and dimensions section of the Owner's Manual.



Dear Audi Driver,

This quick reference guide gives you an overview of the main features and controls of your vehicle. However, it cannot replace the detailed Owner's Manual which contains important information and safety warnings.

Please refer to your Owner's Manual for detailed information on your vehicle. You will find everything you need to know about the radio, CD, navigation, TV and telephone functions in the Operating Manual for your sound system or navigation system.

We wish you safe and enjoyable motoring with your new Audi.

AUDI AG

Controls and displays

1 Unlock switches for:



Tailgate



Tank flap

2 Electric windows

To set the desired position:
Press/pull to the first stop
and hold.

"One-touch" function:
Press/pull briefly to the
second stop.

3 Adjuster for exterior mirrors

Turn the adjuster for:



Left exterior mirror



Exterior mirror heating



Right exterior mirror



Exterior mirror
retraction

Press the adjuster to move
the mirror glass in the desi-
red direction

4 Bonnet lock release

5 Door handle and central locking switch



Lock




Unlock

6 Light switch

7 Headlight range control and daytime running lights

8 Cruise control system

9 Controls on multi-function steering wheel










- 10 Turn signal and main beam lever
- 11 Instruments and warning/indicator lamps
- 12 Windscreen wipers/washer and buttons for on-board computer
- 13 Ignition lock
- 14 Steering wheel position adjuster

- 15 Navigation system or sound system
- 16 Warning lamp for front passenger's airbag
- 17 Air conditioner
- 18 Front passenger's seat heating
- 19 Driver's seat heating
- 20 Gear lever or selector lever for automatic gearbox

21 Ashtray


22 Buttons for:

-  Audi magnetic ride
-  Electronic stabilisation program
-  Hazard warning lights
-  Rear spoiler
-  Activating tyre pressure monitoring

23 Handbrake

Sitting position

Sit in a normal upright position and do not sit too close to the steering wheel. If necessary, also adjust the position of the steering wheel.



Seat adjustment

Electric seat adjustment

1 To adjust lumbar support:

Press the appropriate part of the switch.

2 To adjust seat height and move seat backwards or forwards:

- Front of seat cushion up/down
- Rear of seat cushion up/down
- Seat up/down
- Seat forwards/backwards

3 To adjust backrest:

- Backrest further upright/further reclined



Adjusting head restraints

Take hold of the sides of the head restraint with both hands and move it up as required. The top of the head restraint should be at eye level or higher.

Manual seat adjustment

4 To move seat backwards or forwards:

Lift the lever and move the seat. Then release the lever and move the seat further until the catch engages.

5 To adjust lumbar support:

Press the appropriate part of the switch.

6 To adjust seat height:

Pull up or press down the lever repeatedly.

7 To adjust backrest:

Take your weight off the backrest and turn the knob.

8 Easy entry function:

Pull the lever upwards and fold the backrest forwards.

Starting the engine

Switching on the ignition/starting the engine


Insert the key into the ignition lock.

To switch on the ignition: Turn the key to position ①.

To start the engine (on vehicles with *manual gearbox*): Press the clutch and turn the key to position ② until the engine starts.

To start the engine (on vehicles with *automatic gearbox*): Move the selector lever to position **P** or **N**, press the brake pedal, and turn the key to position ② until the engine starts.

To switch off the engine: Turn the key to position ①.



Automatic gearbox

Selector lever positions


- P** Parking lock
- R** Reverse gear
- N** Neutral
- D** Drive (forwards)
- S** Sport position

To release the selector lever and engage a gear: Switch on the ignition, press the brake pedal, and press the interlock button on the selector lever.

Move the selector lever to **D** or **S** to start driving forwards.

tiptronic: To switch to manual gear selection mode, push the selector lever from position **D** to the right. The gears are shown on the driver information system.

To shift up or down a gear: Briefly push the selector lever forwards or backwards.



Switches for air conditioner

Control on left: Temperature selection

Control in middle: Switching air conditioner on/off and regulating blower speed

Control on right: Air distribution

**Automatic mode**

Set the desired temperature and press the button.

**Air recirculation**

Circulates and filters the air in the interior of the vehicle


**Switching air cooling system on/off****Defrosting windscreen and side windows****Rear window heating**

Audi magnetic ride

Two suspension systems in one vehicle

Normal driving mode: Comfort-oriented suspension

Sport driving mode: Performance-oriented suspension

Press the  switch to activate/deactivate.



Rear spoiler

To increase stability


The down force of the rear axle increases when the rear spoiler is extended.

Automatic mode:

The rear spoiler extends at speeds above 120 km/h and retracts at speeds below 80 km/h.

Manual mode:


Briefly press the  button to extend the rear spoiler.

Briefly press the  button again (while driving between 20 km/h and 120 km/h) to retract the rear spoiler again.

Press and hold the  button (while driving below 20 km/h) to retract the rear spoiler.



Cruise control system

When the system is switched on, the indicator lamp  appears in the instrument cluster.

To switch on/off: Pull/press lever ②.

To set speed: Press button ①.

To adjust stored speed: Press lever up (*faster*) or down (*slower*).

Audi Navigation System plus


Components

① Driver information system

② Multi-function steering wheel

Scroll the **left thumbwheel** to select a menu item in the driver information system. Press the thumbwheel to confirm the selection.

Press the **MODE button** to switch between the active audio source and the navigation and telephone functions.

Briefly press the  button to switch on the speech dialogue system.

Speak after the <beep>, e.g. say <Help> to call up the possible operating commands.

Press and hold the talk button to switch off the speech dialogue system.

Scroll the **right thumbwheel** to adjust the volume.

If you press the right thumbwheel, the last navigation cue will be repeated.





3 Display

4 Function selector buttons

Press one of the buttons (e.g. RADIO) to activate the desired mode.

5 ON/OFF button

To switch on: Press briefly.

To adjust volume: Turn.

To mute: Press briefly.

To switch off: Press and hold.

6 Control buttons

To activate one of the functions shown in the corners of the display, press the control button for that corner of the display.

7 Rotary pushbutton

To select a menu item on display 3:

Turn the rotary pushbutton.

To confirm selection:

Press the rotary pushbutton.

Operating logic

The operating logic for accessing the functions is always the same.



A To call up the menu in a corner of the display: Press the corresponding button.

B To select: Turn the rotary pushbutton.

C To confirm: Press the rotary pushbutton.



- 1 Press the RADIO function selector button.



- 2 Turn the rotary pushbutton and select the desired station.



- 3 Press the rotary pushbutton to confirm.



- 4 Press the control button for "Memory". The control button corresponds to the top left-hand corner of the display.



- 5 Turn the rotary pushbutton and select the desired memory position.



- 6 Press the rotary pushbutton to confirm.



- 1 Press the NAV function selector button.



- 2 Turn the rotary pushbutton and select "Town/ZIP".
- 3 Press the rotary pushbutton to confirm.



- 4 Turn the rotary pushbutton and select the first letter of the destination town.
- 5 Press the rotary pushbutton to confirm.



- 6 Repeat the above step to enter the remaining letters of the destination town until the name of the desired town appears on the display.



- 7 When you have entered the town, turn the rotary pushbutton and select "OK".
- 8 Press the rotary pushbutton to confirm.



- 9 Select "Start route guidance" from the menu.
- 10 Press the rotary pushbutton to confirm. The route will be calculated.

Functions

Establishing a Bluetooth™ connection for a mobile phone


You can quickly connect a Bluetooth mobile phone to the onboard phone system on your navigation system:

- Switch on the ignition, navigation system and mobile phone.
- On your mobile phone, select the menu that looks for Bluetooth devices (e.g. "Hands-free").
- On the mobile phone, select "Audi UHV" and confirm.
- Enter the PIN "1234" on your mobile phone.




Memory cards




















Loading:

- Press the  button to open the display.
- Insert the memory card into the reader slot as shown in the illustration and press in the memory card until you feel it click into place.

Removing:












- Press the  button to open the display.
- Press in the memory card. The card will be released and can then be removed from the reader slot.

Warning and indicator lamps

	Audi magnetic ride		Door/s open
	Tyre pressure too low (check without delay)		Tailgate open
EPC	Engine management ¹⁾		Brake pads worn ¹⁾
	Electronic stabilisation program (ESP)		Light sensor/rain sensor defective
	Emission control system		adaptive light defective
	Main beam headlights		Headlight range control defective ¹⁾
	Rear spoiler		Check engine oil level (lights up permanently)
	Turn signals/hazard warning lights		Engine oil sensor defective ¹⁾ (flashes)
	Fuel level low		Press clutch pedal
	Bonnet open		Washer fluid level low

¹⁾ If this warning lamp lights up when driving, please contact a qualified workshop without delay.

Warning symbols

	Cruise control system		Electro-mechanical power steering
	Airbag system ¹⁾		Fault in the brake system
	Alternator		Fault in the cooling system
	Seat belt warning lamp		Engine oil pressure too low
	Handbrake is applied	<p>If one of these red symbols lights up in the display while you are driving, stop the car immediately, switch off the engine and refer to the Owner's Manual.</p>	
	Anti-lock brake system ¹⁾		
	Electro-mechanical power steering		

© 2007 AUDI AG

AUDI AG reserves the right to alter any part of the vehicle, its equipment and technical specifications. No legal commitment can be implied by the information, illustrations or descriptions in this publication. No part of this publication may be reprinted, reproduced or translated without the written permission of AUDI AG. All rights under the laws of copyright are expressly reserved by AUDI AG. Subject to alteration and amendment. Concept and layout: Pfrieder GmbH. Printed in Germany.

www.audi.com

Audi TT Coupé
Kurzanleitung
englisch 11.07
282.562.812.20