

2012 Audi VIN Decoder

Mfg. Make (1-3)			Series	Engine	Restraint system	Model (7&8)		Check digit	Model year	Assembly plant	Sequential production number (position 12 - 17)					
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
W	U	A	B	F	A	F	L	3	C	1	0	0	2	0	1	2

Series:

A= A4 Premium
A5 Cab Premium
A6 Premium
A8 Sedan
R8 Coupé

B= A3 Avant Premium
A4 Premium q
A6 Premium q
S4 Premium+q
TT & TTS Cpé Prem q

C= A5 Premium q
A5 Cab Premium q
S5 Premium+q
S5 Cab Premium+q
Q5 Premium
Q7 TDI Premium

D= A3 Avant Prem q
A4 Manual Prem q
S4 Manual Prem+q
A6 Premium+
Q5 Premium+
Q7 Prestige S-Line
R8 Coupé - Manual

E= A4 Premium+
R8 Coupé

F= A3 Avant-Man Prem
A4 Premium+q
TT/TTS Cpé Prem+q

G= A5 Manual Prem q
S5 Manual Prem+q
A6 Premium+q
R8 Coupé - Manual

H= A4 Manual Prem+q
A6 Prestige q

J= A5 Cab Premium+
A4 Avant Premium+
A4/S4 Prestige q
TT Cpé Prestige q

L= A5 Premium+q
A5 Cab Premium+q
Q5 Premium+
Q7 TDI Prem+
M= A3 Avant Prem+q
A4/S4 Manual Prestige q

P= A3 Avant-Man Prem+
R= A5 Manual Prem+q
A8 L Sedan

S= A4 Avant Prem q
A7 Prem q
R8 Spyder
TT/TTS Rdstr Prem q

T= A5 Cab Prestige
R8 Manual Spyder

U= A5 Cab Prest. S-Line
R8 Manual Spyder

V= A5/S5 Prestige q
A5/S5 Cab Prestige q
Q7 TDI Prestige
R8 Spyder

W= A4 Avant Prem+q
A5 Prestige q S-Line
A5 Cb Prestige q S-Line
Q5 Prestige
Q7 TDI Prestige S-Line
TT/TTS Rdstr Prem+q

Y= A7 Premium+q
2= A7 Prestige q
3= A5/S5 Man Prestige q
4= A4 Avant Prestige q
A5 Man Prest q S-Line
TT/TTS Rdstr Prest q

9= R8 Coupé GT

TRU = Audi - Hungary: Pass. Car
WAU = Audi - Germany: Pass. Car
WAT = Audi - Europe: SUV
WUA = quattro GmbH - Germany: Pass. Car

See back

FC = A6 / A7
FD = A8
FE = Audi Q7
FG = R8
FH = A5 / S5 Cabriolet
FL = A4 / S4
FK = TT / TTS
FM = A3
FP = Audi Q5
FR = A5 / S5

2012

A = Ingolstadt
D = Bratislava
N = Neckarsulm
1 = Gyor

Calculate per NHTSA Code

E = 4 cyl 2.0L 200hp (CBFA-PZEV*) A3
F = 4 cyl 2.0L 211hp (CAEB) A4 / A4 q / A4 Avant q / A5 q / A5 Cab / A5 Cab q / A6 CVT (C7) / Q5
G = 4 cyl 2.0L 200hp (CCTA) A3 / A3 q
H = 4 cyl 2.0L 211hp (CETA) TT Cpe q / TT Rdstr q
I = V6 3.0L 310hp (CGXB) A6 q (C7) / A7 q
J = V6 3.0L 333hp (CCBA) S4 / S5 Cab
K = V6 3.0L 333hp (CJWB) Q7 S Line
L = V6 3.0L 280hp (CJWC) Q7
M = V6 3.0L 270hp (CALB) Q5
N = V6 3.0L TDI 225hp (CATA) Q7
O = V10 5.2L 525hp (BUJ) R8 / R8 Spyder
P = V10 5.2L 560hp (CMPA) R8 GT
Q = V8 4.2L 430hp (CNDA) R8 / R8 Spyder
R = V8 4.2L 372hp (CDRA) A8 / A8L (D4)
S = V8 4.2L 354hp (CAUA) S5 q
T = 4 cyl 2.0L 265hp (CDMA) TTS Cpe/Rdstr
3 = 5 cyl 2.5L 360hp (CEPB) TT RS q
4 = W 12 6.3L 500hp (CEJA) A8L (D4)
8 = 4 cyl 2.0L 211hp (CHJA) Q5 Hybrid

May 11, 2011 (REV 0a)

* PZEV = Partial Zero Emissions Vehicle

2012 Audi VIN Decoder

Mfg. Make (1-3)			Series	Engine	Restraint system	Model (7&8)		Check digit	Model year	Assembly plant	Sequential production number (position 12 - 17)					
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17

2012 Restraint System:
All = Active - Di/Pass. AirBag - Di/Pass. Advanced Front AirBag
A (A5 / S5 Cab, TT / TTS, R8) = Side AirBags Front, Knee AirBags Front
A (A5 / S5) = Side AirBags Front, Side Guard Air Curtain, Knee AirBags Front
A (A3, A4 / S4, A6 / S6, Q5, Q7) = Side AirBags Front, Side Guard Air Curtain
A (A8 only) = Side AirBags Frt. & Rear, Side Guard Air Curtain, Knee AirBag
B (A3, A4 / S4, A6 / S6, Q5, Q7) = Side AirBags Front & Rear, Side Guard Air Curtain

Calculate per NHTSA Code

Sequential Product Number

K = 1989
L = 1990
M = 1991
N = 1992
P = 1993
R = 1994
S = 1995
T = 1996
V = 1997
W = 1998
X = 1999
Y = 2000
1 = 2001
2 = 2002
3 = 2003
4 = 2004
5 = 2005
6 = 2006
7 = 2007
8 = 2008
9 = 2009
A = 2010
B = 2011
C = 2012